

Broachlink NOAH6 Router Motherboard

Quick Hardware Manual

V1.0.3

ORDER INFORMATION

| NO. | Model | CPU | TPM 2.0 | Frequency | Memory | Micro HDMI | LAN | USB | COM | MiniPCle (wifi) | DC IN |
|-----|------------------------|-------|---------|-----------|--------|------------|---------------------------|-----|-----|-------------------|-------|
| 1 | BL-NOAH6-E3845_V10 | E3845 | NO | 1.91GHz | 1 | 1 | 3*WGI210A T+1*WGI210AS | 4 | 2 | 1 | DC12V |
| 2 | BL-NOAH6-E3845.TPM_V10 | E3845 | YES | 1.91GHz | 1 | 1 | 3*WGI210A T+1*WGI210AS | 4 | 2 | 1 | DC12V |

CE Declaration of Conformity

We, the undersigned,

Manufacturer: Broachlink Technology

Address: 1212, Yongtong BLDG, RenMin North Rd., LuoHu Dist., Shenzhen City, China

declare, that the product

Product name: System board NOAH6, NOAH6.TPM

conforms to the following Product Specifications and Regulations:

EMC:

EN 55032:2015

EN 55035:2017

EN 61000-3-2:2014

EN 61000-3-3:2013

IEC 61000-4-2

IEC 61000-4-3

RoHS:

EN 62321-1:2013 (IEC 62321-1:2013)

The product herewith complies with the requirements of the EMC directive 2014/30/EU, and the RoHS directive 2011/65/EU and carries the CE marking accordingly.



Richard Deng / President

Shenzhen, August 20, 2023

FCC Declaration of Conformity

We, the undersigned,

Manufacturer: Broachlink Technology

Address: 1212, Yongtong BLDG, RenMin North Rd., LuoHu Dist., Shenzhen City, China

declare, that the product

Product name: System board NOAH6, NOAH6.TPM

conforms to the following Product Specifications and Regulations:

FCC Part 15, Subpart B, Unintentional Radiators

Supplementary Information:

The device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.




Richard Deng / President

Shenzhen, August 20, 2023

Compliance notes

Test reports available on request. Please note that further compliance testing at the system level may be required for CE mark when other modules such as wireless cards are added.

Recycling / disposal



Do not discard electronic products in household trash! All waste electronics equipment should be recycled according to local regulations.

Information for the recycler:

Remove the CR2032 button battery for separate recycling.

Our enclosures are made of aluminum.

Chapter 1 Introduction

1.1 About Noah


Broachlink NOAH series motherboard are designed for fanless network appliance, like router, firewall, VPN, IPBX, IoT gateway etc. Deeply electronic, mechanical, and software optimized for perfect operation on open source operating systems such as CentOS, OpenBSD, OPNsense, and FreeBSD. The ideal choice for open source community users and geek users. The optimized electronic design enables the product to have ultra-low power consumption, which is 20 % lower than competitive products. The enhanced thermal design gives the product a significant stability advantage in a compact housing, especially in a closed housing. The rich extension features allow end users to flexibly respond to various communication scenarios. In order to help customers quickly achieve product launch, we can provide .step 3D files of the product.

1.2 Specification

| | |
|--------------------------|--|
| Processor | CPU: Intel Atom E3845,4 cores,1.91Ghz,2MB L2,AES-NI |
| | BIOS: AMI 64 Mbit |
| Memory | Technology: DDR3L 1333MHz |
| | Max. Capacity: 8 GB |
| | Socket: 1 x 204 pin SODIMM |
| Display | 1 x HDMI, Maximum Resolution: up to 2560x1600 at 60 Hz |
| Ethernet | Interface: 1 x Giga SFP + 3 x RJ45 |
| | Controller: Intel I210AS Gigabit , Intel I210AT Gigabit |
| WatchDog | Output: System reset |
| Timer | Internal Watchdog timer: programmable 1-255s,1-255min, disable |
| Storage | mSATA: 1 x full size mSATA |
| | eMMC: 1 (eMMC 4.5, Support Broachlink eMMC Module) |
| | SATA: 1 x SATAII (Max. Data Transfer Rate up to 3.0 Gb/s) |
| Internal I/O | Up to 3 Serial: 1 x RS-232 ,2xTTL (Transfer rate up to 1 Mbit/s) |
| | HDMI: 1 |
| | Reset Button: 2 |
| | Power Button: 2 (For system wake) |
| | USB: 3 x USB2.0 + 1 x USB3.0 |
| | GPIO: 20-bit GPIOs |
| Expansion | MINI_PCIE1 for 4G / Lte, MINI_PCIE2 for 4G / Lte,Wifi |
| Power | Power input: 12V \pm 10% only |
| | Power Consumption (Typical,Minimum system) Noah with E3845: 0.5A @ 12V (5.28W) |
| | Power Consumption (Max, test in pfSense) Noah with E3845: 1A @ 12V (12W) (Without any addon card on miniPCI slot) |
| Environment | Operating 0 ~ 60° C (32 ~ 140° F) (Operating humidity: 40° C @ 95% RH non-condensing) |
| | Non-Operating -40° C ~ 85° C and 60° C @ 95% RH non-condensing |
| Physical Characteristics | Dimensions (L x W): 160 x 152 mm (6.3" x 5.99") |
| | Weight: 0.45 kg (0.99 lb) (with heatsink) |
| | Total Height: (with cooler + PCB + Bottom) 33mm |

Chapter 2 Connectors

2.1 Dimension




NOAH6 Dimension


2D/3D file are available. Please contact factory for more info.

broachlink@gmail.com


2.2 NOAH6 Connectors Layout



NOAH6 connectors layout at the top



NOAH6 connectors layout at the bottom




NOAH6 I/O ports layout

2.3 Connectors List

ETH1,ETH2,ETH3,ETH4,COM1

Compact design for small enclosures.




COM1 Definition

RJ45 console port. Support remote PC accessing.

| PIN | NAME | PIN | NAME |
|-----|------|-----|------|
| 1 | RTS | 2 | DTR |
| 3 | TXD | 4 | GND |
| 5 | GND | 6 | RXD |
| 7 | DSR | 8 | CTS |

Support typical baud rate from 9600bps ~ 115200bps (115200 default).

Baud rate setting in BIOS



Baud rate setting in freeBSD


```
root@:/ # vi /boot/loader.conf
```

```
console="comconsole"           // select serial port as console
```

```
comconsole_speed=115200       // 115200 is recommended
```

```
autoboot_delay="0"           // waiting time setting
```

Recommended settings on PuTTY (remote windows PC)



SFP1 (ETH1)

The port support Giga SFP fiber module, or SFP RJ45 module.



ETH2,ETH3,ETH4 Definition

| PIN | NAME | PIN | NAME |
|-----|--------|-----|--------|
| 1 | MDI_0+ | 2 | MDI_0- |
| 3 | MDI_1+ | 4 | MDI_2+ |
| 5 | MDI_2- | 6 | MDI_1- |
| 7 | MDI_3+ | 8 | MDI_3- |

In FreeBSD, ETH1~ETH4 correspond to igb0~igb3 respectively.

```
root@:~ # uname -a
```

```
FreeBSD 12.0-RELEASE FreeBSD 12.0-RELEASE r341666 GENERIC amd64
```

```
root@:~ # dmesg | grep address
```

```
igb0: Ethernet address: 1c:ae:3e:e6:22:6a ETH1 the SFP port
```

```
igb1: Ethernet address: 1c:ae:3e:e6:22:6b ETH2
```

```
igb2: Ethernet address: 1c:ae:3e:e6:22:6c ETH3
```

```
igb3: Ethernet address: 1c:ae:3e:e6:22:6d ETH4 network port close to COM1
```

IP setting

```
root@:~ # vi /etc/rc.conf
```


```
clear_tmp_enable="YES"
sendmail_enable="NONE"
hostname=""
#ifconfig_igb0="DHCP" // dhcp
ifconfig_igb0="inet 192.168.1.210 netmask 255.255.255.0" // static IP of igb0
ifconfig_igb1="inet 192.168.2.210 netmask 255.255.255.0"
ifconfig_igb2="inet 192.168.3.210 netmask 255.255.255.0"
ifconfig_igb3="inet 192.168.4.210 netmask 255.255.255.0"

sshd_enable="#YES"
# Set dumpdev to "AUTO" to enable crash dumps, "NO" to disable
dumpdev="AUTO"
sshd_enable=yes // sshd setting
```

COM2 (BLANK)

It's the copy of RJ45 console port COM1, RS232 level.


The port would be available as soon as pin header has been soldered.



| PIN | NAME |
|-----|------|
| 1 | TXD |
| 2 | RXD |
| 3 | GND |

COM3 (TTL level)


The both TTL level serial ports are from a USB bus convert chip CH340.



| PIN | NAME |
|-----|------|
| 1 | TXD |
| 2 | RXD |
| 3 | GND |

I2C1(BLANK)


The port would be available as soon as pin header soldered.





| PIN | NAME |
|-----|------|
| 1 | DATA |
| 2 | CLK |
| 3 | GND |

HDMI1

HDMI1 is micro HDMI female connector. Please use a micro HDMI male to HDMI female cable to connect monitor to NOAH6.




RST_PWR_BTN1




| POSITION | FUNCTION |
|----------|--------------|
| Upper | Power Button |
| Lower | Reset Button |


FRONT_PWR_BTN1, FRONT_RST_BTN1, MODE_SW1



| PIN | NAME |
|--------------------|---|
| MODE_SW1 | GPIO pin. GPIO_S0_SC56 of SOC (pin BC12). |
| FRONT_RST_BT N1 | Reset Button |
| FRONT_PWR_BT N1 | Power Button |



LED1,LED2,LED3




LED1 LED2 LED3


| NAME | FUNCTION |
|------|---|
| LED1 | GPIO pin. Wired out from GPIO_S0_SC60 of SOC (pin BD16). |
| LED2 | GPIO pin. Wired out from GPIO_S0_SC59 of SOC (pin BF14). |
| LED3 | GPIO pin. Wired out from GPIO_S0_SC58 of SOC (pin BC14). |

E3845

- BD12
- GPIO_S0_SC55 ← BC12 GPIO_S0_SC56
- GPIO_S0_SC56 ← BD14
- GPIO_S0_SC57
- GPIO_S0_SC58 ← BC14 SOC_LED3_GP58 <> SOC_LED3_GP58
- GPIO_S0_SC59 ← BF14 SOC_LED2_GP59 <> SOC_LED2_GP59
- GPIO_S0_SC60 ← BD16 SOC_LED1_GP60 <> SOC_LED1_GP60
- GPIO_S0_SC61 ← BC16 GPIO_S0_SC61




HDD_LED1,PSU_LED1, LAN0_SPD_LED1,ACT_LED1,ACT_LED2,ACT_LED3



ACT_LED1 ACT_LED3 HDD_LED1
LAN0_SPD_LED1 ACT_LED2 PSU_LED1


| NAME | FUNCTION |
|---------------|---|
| HDD_LED1 | HDD Activity light, blink when HDD in reading/writing. |
| PSU_LED1 | Power Status. Light off in case system is in shutdown (S4). |
| LAN0_SPD_LED1 | Activity LED of SFP1 (ETH1) |
| ACT_LED1~3 | Activity LED of ETH2~4 |

The 2 led on top of RJ45 serial port are copy of HDD_LED1 and PSU_LED1.



J1

12V power in DC jack, 5.5mm x 2.5mm. It is recommended to use a power supply validated by us to ensure the reliability of the appliance.





| PIN | NAME |
|-------------|-----------------------|
| Central pin | +12V1 (ALWAYS ON) |
| Another pin | GND |

J2

J2 and J1 is wired OR logic, it can be arranged for backup input , depends on client's demand.

This pin header is compatible with Broachlink UPS,POE,PSE cards.





| PIN | NAME |
|-----|---------------------|
| 1 | +12V1 (ALWAYS ON) |
| 2 | GND |

Caution:

12V_S (OFF IN S4) and +12V1 (ALWAYS ON) are different power rail.


Don't wire +12V1 to 12V_S , Short them would damage the motherboard.

USB1



| Position | USB Speed |
|------------|-----------|
| Upper port | USB2.0 |
| Lower port | USB3.0 |


USB2



| PIN | NAME | PIN | NAME |
|-----|------|-----|------|
| 1 | VCC | 2 | VCC |
| 3 | D0- | 4 | D1- |
| 5 | D0+ | 6 | D1+ |
| 7 | GND | 8 | GND |
| | | 10 | GND |




MSATA1 (SSD)

Support mSATA SSD. SATA 2.0 , 3.0 Gb/s.



MINI_PCIE1 (4G/Lte, Wifi)


Support Wifi , and 4G/LTE module with SIM holder SIM2 (bottom)



J10

The jumper is used for setting voltage of 4G card in MINI_PCIE1.

In a poor signal environment, if the 4G card can accept maximum voltage of 4V, it is strongly recommended to set this jumper to 3.8V.





| Jumper setting | Voltage of MINI_PCIE1 |
|-----------------|-----------------------|
| 1-2 (default) | 3.4V |
| 2-3 | 3.8V |

MINI_PCIE2 (4G/Lte, Wifi)

The slot support the wifi cards, PCIe Gen2.

Broachlink copper and optical mini PCIe network cards are compatible with the slot.



SATA1,PWSATA2

Support SATA 3.5/2.5 inch Hard drive. SATA 2.0 , 3.0 Gb/s (300 MB/s)




SATA1 definition

| PIN | NAME |
|-----|------|
| 1 | GND |
| 2 | TXP |
| 3 | TXN |
| 4 | GND |
| 5 | RXN |
| 6 | RXP |
| 7 | GND |

PWSATA2 definition

| PIN | NAME |
|-----|-------|
| 1 | VCC |
| 2 | GND |
| 3 | GND |
| 4 | 12V_S |

RESET1



| PIN | NAME |
|-----|---------------------------------------|
| 1 | Power button |
| 2 | GND |
| 3 | GND |
| 4 | RESET# |
| 5 | Watchdog_trigger# Active-Low level |

Shorting pin 4~5 means the watchdog will trigger a system reset after WDT timeout.

Users can also refer to the marks on the bottom of the PCB to wire out the pin headers.

JGPIO1,JGPIO2,JGPIO3

NOAH6 has three headers that support up to 20 channels 3.3V GPIO signals. 16 channels are controlled by SOC E3845, and the remaining 4 channels are controlled by SUPER IO IT8772.



JGPIO1 (SOC source)

| PIN | NAME | PIN | NAME |
|-----|------|-----|------|
| 1 | GP0 | 2 | VCC3 |
| 3 | GP1 | 4 | GP6 |
| 5 | GP2 | 6 | GP7 |
| 7 | GP3 | 8 | GP8 |
| 9 | GND | 10 | GP9 |


JGPIO2 (SOC source)

| PIN | NAME | PIN | NAME |
|-----|------|-----|------|
| 1 | GP22 | 2 | VCC3 |
| 3 | GP23 | 4 | GP27 |
| 5 | GP24 | 6 | GP28 |
| 7 | GP25 | 8 | GP29 |
| 9 | GND | 10 | GP30 |


JGPIO3 (Super I/O source)

| PIN | NAME |
|-----|------|
| 1 | GP52 |
| 3 | GP51 |
| 5 | GP37 |
| 7 | GP36 |
| 9 | GND |

In order to help developers carry out secondary development on NOAH, broachlink has released GPIO development tools, including BL-GPIO-KIT (purchase separately) 3 x 8 CH GPIO card, and FreeBSD, Linux, windows demo code. Contact broachlink@gmail.com for more info.




EMMC1



| PIN | NAME | PIN | NAME |
|-----|------------|-----|----------|
| 1 | eMMC_D0 | 2 | eMMC_D1 |
| 3 | eMMC_D2 | 4 | eMMC_D3 |
| 5 | eMMC_D4 | 6 | eMMC_D5 |
| 7 | eMMC_D6 | 8 | eMMC_D7 |
| 9 | NC | 10 | GND |
| 11 | eMMC_CMD | 12 | eMMC_CLK |
| 13 | 3.3VSB | 14 | GND |
| 15 | 1.8VSB | 16 | 1.8VSB |
| 17 | eMMC_RESET | 18 | 3.3VSB |
| 19 | GND | 20 | GND |

Battery holder (No battery)

For safe transportation reasons, the button battery is not assembled by default.



| PIN | NAME |
|------------|----------|
| Pin On PCB | Negative |
| Upper Pin | Positive |

